


### A UNIVERSAL & INNOVATIVE ENERGY MANAGEMENT SYSTEM







# EFFICIENCY

TAKING EFFECTIVE ACTION TO ENSURE ENERGY EFFICIENCY NOT ONLY REDUCES ENERGY CONSUMPTION AND GREENHOUSE GAS EMISSIONS, BUT ALSO YIELDS FINANCIAL BENEFITS **AS WELL AS EASIER USE AND FUNCTIONING OF INSTALLATIONS.** 

#### **L**legrand<sup>®</sup>

|  |                 | -                                     |           |
|--|-----------------|---------------------------------------|-----------|
|  | ()              | LEGRAND SOLUTIONS                     | 03        |
|  |                 |                                       |           |
|  |                 |                                       |           |
|  |                 |                                       |           |
|  |                 | Actions and functions                 |           |
|  |                 | Advantages                            |           |
|  |                 | CX <sup>3</sup> EMS (ENERGY MANAGEMEN | T SVSTEM) |
|  |                 | An innovative supervision system      |           |
|  |                 | A complete and compact system         |           |
|  |                 | Simple to choose                      | 12        |
|  |                 | Simple to configure                   |           |
|  |                 | Adaptable for all installations       |           |
|  |                 |                                       |           |
| 24.  |                 | CATALOGUE PAGES                       | 22        |
|  |                 |                                       |           |
|  |                 |                                       |           |
|  | 2.5.36          |                                       |           |
|  | 111             |                                       |           |
|  |                 |                                       |           |
|  | Hilling & Frank |                                       |           |
| all a second in  |                 |                                       |           |
|  |                 |                                       |           |
| And the second |                 |                                       |           |
| States States  | 4               |                                       |           |
| A Malatan Star   | - ali           |                                       |           |
|  | 1               | 1.00                                  |           |
| the sign better in the part  |                 |                                       |           |
| North March 1996   | 1 Steel         |                                       |           |
| A Martin Martin  |                 |                                       |           |
| Marine Marine Marine 3   |                 |                                       |           |
| STAN STAND   | S C             |                                       |           |
| all the second |                 |                                       |           |
| A CARACTER AND   | A THE           |                                       |           |
|  | and all         |                                       |           |
| la ki k  |                 |                                       |           |
| 1 And  | 1 h             |                                       |           |
|  |                 |                                       |           |
|  | 17              |                                       |           |
| Mint .   | 1 19            |                                       |           |
|  |                 | D                                     |           |
|  |                 | ALC: NOT                              |           |
|  |                 |                                       |           |
|  |                 |                                       |           |
|  |                 |                                       |           |
|  |                 |                                       |           |
|  | 14 4 100        |                                       |           |
|  |                 |                                       |           |
|  |                 |                                       |           |

4



#### The Legrand ENERGY MANAGEMENT

system was created to supervise and manage energy consumption within the building, guaranteeing reliability and continuity of service for maximum efficiency.

AWARENESS OF ENERGY CONSUMPTION is the FIRST STEP towards energy efficiency.

CONTROLLING IT is the SECOND, ...

#### La legrand®



## Legrand solutions

Legrand offers various solutions for **MEASURING and SUPERVISING** electrical systems that can adapt to all needs and offer total control and manageability.

The versatility of Legrand solutions ensures they will interface with other ENERGY MANAGEMENT systems.



#### SIMPLE INSTALLATIONS THAT MEASURE CONSUMPTION

devices for measuring electrical values and data collection.

#### AUTOMATED INSTALLATIONS

devices for monitoring and automating distribution panels to guarantee continuity of service and timely control of the installation.

#### CENTRALISED INSTALLATIONS

systems for all-round supervision of installations, providing full functionality for optimal management of all devices.

## ENERGY MANAGEMENT Constructions...

The **Legrand CX<sup>3</sup> EMS energy management system** allows you to control your installation in just a few steps.





#### set

Set the system with functions that are customised to your needs.



#### configure

Programme all devices, locally and remotely, so they can communicate with one another and with other external systems.



#### supervise

Monitor and control all processes using IT tools to optimise energy consumption anytime, anywhere.

### ... and functions





#### register

Register the consumption of all installation users.



#### measure

Measure analogue or electrical values (current, voltage, power, etc).

#### signalling

Display the status of electrical protection devices or circuits, both locally and remotely.



#### control

Operate electrical protection devices or motorised controls, both locally and remotely, by means of manual or automatic actions.



#### communicate

Send all information remotely from the electrical switchboard.



#### display

Display the data locally or remotely, on built-in screens or on PCs, smartphones or tablets with an internet connection.



The CX<sup>3</sup> EMS energy management system allows precise management and use of energy within a building. It allows full control of all activities in order to improve their functioning by anticipating possible breakdowns.

#### Counting and measuring consumption to **REDUCE COSTS**



- **be aware** of consumption
- control consumption
- **adopt** a constant operating regime to smooth out consumption over time

Monitor and control the installation status to ENSURE CONTINUITY OF SERVICE



- visualise and assess technical alarms in real time
- find out the installation status
- prevent damage to parts of the installation

#### Analyse data to IMPROVE PROCESSES




- **determine** annual energy needs to define how consumption is distributed
- **analyse** the trend over time to control performance
- log events to prevent critical issues


#### L<sup>1</sup> legrand<sup>®</sup>

#### MAXIMUM NUMBER OF FUNCTIONS AND ACTIONS = MINIMUM NUMBER OF INTERVENTIONS AND CONSUMPTION

In an electrical infrastructure, having more functions and actions reduces the number of human interventions and makes a major contribution to **optimising final consumption**.




⊕ WWW.LEGRAND.COM



### an innovative supervision system

**CX<sup>3</sup> EMS is the simplified supervision system** able to display, measure and control the installation locally or remotely. An add-on autonomous system, which, thanks to the innovative automatic connection system, is easy to assemble and does not require any changes to the existing panel wiring.

#### La legrand®



#### COMPLETE AND COMPACT

#### The CX<sup>3</sup> EMS supervision

**system**, with its extremely compact design, offers all the functions you need for complete installation supervision.

- measurement
- status (ON/OFF/fault)
- control
- pulse counting
- serial communication
- display

#### SIMPLE

#### SIMPLE TO CHOOSE

Only 14 modules with dedicated functions for supervising any installation.

#### SIMPLE TO INSTALL

Quick, pre-cabled connections on a communication rail or with patch cords that do not hinder electrical switchboard cabling.

#### SIMPLE TO CONFIGURE

Configuration both directly from the panel without the help of a PC and via dedicated software that can be downloaded from the Legrand website via the E-Catalogue.


#### ADAPTABLE

### TO SUIT ANY PROTECTION DEVICE

The CX<sup>3</sup> EMS modules are compatible with any type of protection device (modular or power), whatever the brand.

#### FOR NEW AND EXISTING PANELS

Its compact dimensions and the possibility of connecting the system via 2 different solutions make it easy to install in new or existing switchboards.



With the same performance as the "classic" measuring units, the CX<sup>3</sup> EMS measuring modules can be used to measure the electrical energy consumed by a singlephase or three-phase circuit and the various electrical values:

- Active (kW), reactive (kVAR) and apparent (kVA) power on all phases or cumulative
- Simple and compound voltages
- Current consumption on each phase
- Frequency and Cos  $\boldsymbol{\phi}$
- Harmonics

Concentrator module for energy metering by means of pulses: collects data from meters with pulse output such as electricity meters or water and gas meters, etc.

Up to 3 pulse circuits.

Compact modules indicating the status of the associated device: Contacts:


- open
- closed
- triggered

In addition, for the LED version:

- MCCB plugged-in/ drawn-out
- springs loaded for opening/closing of ACBs



All the modules in the **CX<sup>3</sup> EMS supervision system** have compact dimensions, in order to minimise the space taken up in the electrical switchboard.



Universal control module. Used to remotely control different electrical loads such as relays, contactors, and motorised controls on modular or power circuit breakers, whatever their brand. The control and status reporting module is used to remotely control and display the status of the Legrand 1 and 2-module contactors up to 25 A, as well as pulseoperated latching relays. The EMS CX<sup>3</sup>/RS 485 communication interface allows the conversion of data from the EMS CX<sup>3</sup> network to the MODBUS RS 485 network, in order to display and manipulate the data outside the electrical enclosure.

Stand-alone configuration module for controlling the entire installation, locally, in the enclosure:

- system configuration
- test
  - consumption display
  - alarm control
  - device control
  - memorising alarms



The CX<sup>3</sup> EMS system consists of DIN rail The CX<sup>3</sup> EMS system **does not** require a minimum number mounting modules. of modules and it also makes monitoring easy. Thanks to its scalability, **new** functions can be added at any COMMUNICATION time depending on the needs of the installation. ĩ SIGNALLING MEASUREMENT **COMMUNICATION**  $oldsymbol{O}$ MEASUREMENT **CONTROL** SIGNALLING CONTROL MEASUREMENT MEASUREMENT SIGNALLING • 1-1-2 X1-8 X2-8 - C 3-R2-4 250 V~ - 6A 0 O if (1) 149.2 O i2 CA+SD DX3 B32 6000 3 10 kA 005.98 1.02.1 4500 [3] legrand legrand legrand egrand legrand legrand earand legrand egra 12



### ...simple to install

### Quick and simple data connection

In both cases, data connection is simple and immediate and **does not require any other additional space in the electrical enclosure.** 

If using the communication rail, connection is made automatically via the rear contacts, when the CX<sup>3</sup> modules are fixed on the DIN rail of the electrical panel.

#### The **CX<sup>3</sup> EMS system is powered at safety extra low voltage (SELV)** and has 2 types of connection:

- by means of the innovative **communication rail** system
- by means of the quick-fit **patch cords**.

#### **COMMUNICATION RAIL**

Connection is made automatically with the connectors at the rear of the CX<sup>3</sup> EMS modules.

#### PATCH CORDS


All CX<sup>3</sup> EMS modules have ports at the bottom for connection to the bus via patch cords.



CX<sup>3</sup> EMS ENERGY MANAGEMENT SYSTEM PRODUCT GUIDE 13

## CX<sup>3</sup> EMS simple to configure

The CX<sup>3</sup> **EMS system** has been developed in order to be able to manage, simply and immediately, all functions (measurement, signalling and control), both locally from the electrical panel by means of configuration modules and remotely by means of free dedicated software.



### FUNCTION CONFIGURATION

The universal signalling and control modules include 4 DIP switches that enable different function types to be set.



#### **ADDRESS CONFIGURATION**

All the modules are equipped with a selector for configuring the address locally.



## 

All the modules are also equipped with a multifunction 3-colour LED button to instantly identify the operating status: correct operation, on stand-by, being programmed,

being updated, no EMS communication, etc.



#### : PROGRAMMING AND DISPLAY

The stand-alone EMS configuration module can be used to configure the system and to visualise all the installed modules, without needing an IP or PC connection.




#### 



## 

The PC (with pre-installed software) and the EMS CX<sup>3</sup> interface Cat.No 4 149 40 or mini-configurator Cat.Nos 4 149 36/37 can be connected directly using a USB/USB micro cable, or remotely via an IP network and a MODBUS/IP gateway Cat.No 0 046 89.





The software can be used to detect all EMS CX<sup>3</sup> modules in the system and assign them an address automatically. The numerical selector switches must be in position "0".

| 0 test •                               |  | Read configuration      | n from USB          |                     |      |   |
|--|--|-------------------------|---------------------|---------------------|------|---|
|  |  | Found:<br>12 module     |                     |                     | 0    |   |
| _                                      | Press "Continue" to import   | structure ignoring faut |                     | "Retreats" to retry | -    |   |
| _                                      | Model  | Module ID               | Address             | Result              | FW E |   |
|  | REAL PROPERTY  | 0000-0000-0019-1281     | 10                  | 1                   | 1    |   |
|  | Manue propagate the  |                         |                     | 1                   | 1    | 1 |
|  | Danay  | 2503-2000-0018-4545     |                     | 1                   | 1    |   |
|  | Nature (CT)  |                         |                     | 1                   | 1    |   |
|  | Denny Deneral  | 9099-0090-0008-4C80     |                     | 1                   | 1    |   |
|  | Garrent A Starte (CTL)(R)  |                         |                     | 1                   | 1    |   |
|  | State participants   | 1001-0000-0038-0823     | 14                  | 1                   | 1    |   |
|  | Cantral (many Arrian)  |                         | 18.                 | 1                   | 1    |   |
|  |  |                         |                     |                     |      |   |
| ······································ | Free produce investi   | 0000-0000-0080-73PC     | 81                  | 1                   | 1    |   |
| ······································ | Disk (molum throw)<br>Disk former:<br>con on the bally to light the LED on the | 0000-0000-0080-739C     | H<br>H<br>O Refresh | - 1                 | 12   |   |

## CONFIGURING

The software can be used to assign different operating types to the universal modules. The micro-switches must be in position "0".



## EMS CX<sup>3</sup> adaptable for all installations

EMS CX<sup>3</sup> modules are optimised for simple, compact installation and are easily integrated in new or existing installations, in association with DIN rail mounting circuit breakers such as DX<sup>3</sup> or MCCBs such as DPX<sup>3</sup> and DMX<sup>3</sup>.

#### SIGNALLING

The universal, configurable signalling module can be associated with all type of signalling auxiliaries on DIN rail mounting MCBs or power circuit breakers:

- DX3
- DPX<sup>3</sup>
- DMX<sup>3</sup>



#### . CONTROL

Used to locally or remotely control different electrical loads or motorised controls associated with DIN rail mounting protection devices or supply end equipment. Equipped with DIP switches (on the side) allowing product configuration:

- contact type
- of functions (maintained or momentary contact)

#### : MEASUREMENT UP TO 125 A

Measurement modules with closed Rogowski coils can be used to take measurements on a three-phase circuit up to 63 A or 125 A, or on three single-phase circuits, with a single module up to 63 A.





### up to 6300 A

EMS CX<sup>3</sup> measurement modules with flexible open Rogowski coils or with current transformers are ideal for the needs of installations up to 6300 A



#### MEASUREMENT WITH OPEN COILS

Three-phase measurement modules with flexible open Rogowski coils can be used to measure currents up to 630 A, 1600 A, 3200 A and 6300 A, depending on the size chosen. They have been specially designed for quick and easy installation. The supports provided are used to fix and centre the coils on the busbars horizontally or vertically.












#### MEASUREMENT WITH CT

High-current measurement modules for current transformers can be used to take measurements using conventional current transformers (5 A). They can therefore be used in large distribution panels.



## CX<sup>3</sup> EMS application examples







#### **"STAND-ALONE"** CONFIGURATION

#### IDEAL FOR INDIVIDUAL INSTALLATIONS

WHERE THERE IS A LOCAL NEED TO:


- monitor parameters (electricity, water, gas, heat, etc.) during consumption and/or production
- check the status of various devices (switches, contactors, relays, end runs, etc)
- locally control various devices (switches, contactors, relays, etc)
- register alarms (up to 20)
- generate simple load control automations
- configure the installation simply

#### Scope of **application**:

Residential buildings and small commercial businesses potentially with photovoltaic and/or thermal solar energy production plants.

#### Installation

- maximum capacity for expansion: 32 devices
- maximum distance between two devices: 3 m
- maximum consumption of the entire system: 1500 mA, divided into 3 interconnected groups
- maximum consumption of each group: 500 mA supplied by a single power supply (Cat.No 4 149 45)



#### La legrand®

### 

#### CONNECTED CONFIGURATION

#### **IDEAL FOR INDIVIDUAL INSTALLATIONS** WHERE, IN ADDITION TO THE SERVICES DESCRIBED IN EXAMPLE 1, THERE IS A NEED TO:


- record the trend of various electrical parameters (voltage, current, power, power factor, frequency, harmonic distortion rate, etc)
- create histograms and energy reports
- record events and alarms
- save data to files and automatically send out emails/text messages
- implement automation and load management systems
- access the system via various devices (smartphones, tablets, PCs, etc)

#### Scope of **application**:

Residential buildings and small commercial businesses where the need, above all, is to make installation monitoring and control possible from a remote location.

#### Installation

- maximum expansion possible: 32 devices
- maximum distance between two devices: 3 m
- maximum consumption of the system: 1500 mA, divided into 3 interconnected groups
- maximum consumption of each individual group: 500 mA supplied by a single power supply (Cat.No 4 149 45)







## CX<sup>3</sup> EMS application examples







#### **"ON-LINE"** CONFIGURATION

**IDEAL FOR INSTALLATIONS** WHERE, IN ADDITION TO THE SERVICES DESCRIBED IN EXAMPLE 2, IT IS POSSIBLE TO INTEGRATE INDIVIDUAL BUS EMS SYSTEMS BETWEEN THEM AND OTHER MODBUS DEVICES ABLE, FOR EXAMPLE, TO:

- additional measurement and control functions
- manage and monitor the parameters of electronic protection relays typical of large switches (boxed and open)
- manage and monitor the automatic switching parameters between two power sources, etc


TABLET OR

#### Scope of **application**:

Buildings with simple installations, also consisting of several electrical cabinets, with the need to control and monitor electrical loads.

#### Installation

- maximum capacity for expansion: 32 MODBUS devices
- maximum length of RS485 bus: 1000 m
- maximum logical addresses: 247



#### La legrand®



€ WWW.LEGRAND.COM



**IDEAL FOR INDIVIDUAL PLANTS** WHERE, IN ADDITION TO THE SERVICES DESCRIBED IN EXAMPLE 3, THERE IS A NEED TO:


- remotely manage individual installations in different locations with the help of devices (smartphone, tablet, PC, etc) connected to the internet
- have several display levels: local (1 site) or remote, with a multi-site "administrator" view.

#### Scope of **application**:

Sites (bank branches, fuel sales points, chains of stores or restaurants, schools, etc) with simple installations requiring supervision by a single administrating entity

#### Installation

- maximum capacity for expansion: 32 MODBUS devices 32 devices
- maximum length of RS485 bus: 1000 m
- maximum logical addresses: 247



CX<sup>3</sup> EMS - ENERGY MANAGEMENT SYSTEM PRODUCT GUIDE 21

#### **C**legrand

#### CX<sup>3</sup> energy management system



#### Conform to IEC/EN 61131-2 (Programmable controllers)

CX<sup>3</sup> energy management system enables to measure, control and visualize the state of <u>r</u> rail mounting protection devices (MCBs, RCCBs, RCBOs, etc...) and head equipment (DMX<sup>3</sup> and DPX<sup>3</sup>), locally ("Stand alone") or remotely. All the modules of the system are equipped with two specific communication ports: one at the backside (for communication rail) and one underneath (for communication patch cords). Power supply with specific module Cat.No 4 149 45 Remote configuration possible with the help of the Energy Management Configuration Software, available for free download via E-Catalogue (giving also access to a 30-day trial version of Energy Management Software Cat.No 4 149 38/39)

| Pack        | Cat.Nos     | Measurement modules  |                              | Pack | Cat.Nos               | Pulse concentrator  |                            |
|-------------|-------------|--|------------------------------|------|-----------------------|---|----------------------------|
|             |             | For measuring current, voltage, active/reac<br>power and other values<br>Conform to IEC/EN 61557-12<br>Accuracy: class 0.5<br><b>Direct connection up to 63 A with</b><br><b>closed Rogowski coils</b>   | tive<br>Number<br>of modules | 1    | 4 149 26¹             | For collecting and transmitting<br>measurements taken by universal pulse<br>energy meters (water, gas, etc)<br>Up to 3 pulse circuits<br>Consumption: 0.288 W - 24 mA (12 V = )   | Number<br>f modules<br>1   |
|             |             | Allow the passage of prong-type supply busbars (upper side)  |                              |      |                       | State reporting modules   |                            |
| 1<br>1<br>1 |             |  | 1<br>1<br>1                  | 1    | 4 149 29 <sup>1</sup> |   | Number<br>f modules<br>0.5 |
| 1           | 4 149 21    | Consumption: 0.418 W - 34.8 mA (12 V =)<br><b>Direct connection up to 125 A with</b><br><b>closed Rogowski coils</b><br>Allow the passage of prong-type supply<br>busbars (upper side)<br>Supplied with closed Rogowski coils<br>3-phase measuring module + 3 coils<br>Consumption: 0.418 W - 34.8 mA (12 V =) | 1                            | 1    | 4 149 30 <sup>1</sup> | Universal signalling module<br>Equipped with 3 LED lights: green, red<br>and yellow<br>Indicates various type of information,<br>according to selected configuration:<br>contacts position, plugged-in or drawn-out<br>product, etc<br>Equipped with DIP switches (on the side) | 1                          |
|             | 4 4 4 9 9 9 | Direct connection with open, fexible<br>Rogowski coils<br>Allow the passage of prong-type supply<br>busbars (upper side)<br>Supplied with opened, fexible Rogowski<br>coils and fixing supports for busbars  |                              |      |                       | allowing product configuration: selection of<br>information type and of the LED behaviour<br>Compatible with rail mounting<br>protection devices or head equipment<br>(DMX <sup>3</sup> and DPX <sup>3</sup> )<br>Consumption: 0.377 W - 31.4 mA (12 V = )                      |                            |
| 1           | 4 149 22    | 3-phase measuring module +<br>3 coils up to 630 A  | 1                            |      |                       | Universal control module  | Number                     |
| 1           | 4 149 24    | Consumption: 0.418 W - 34.8 mA (12 V =)<br>3-phase measuring module +<br>3 coils up to 1600 A  | 1                            | 1    | 4 149 32 <sup>1</sup> | 2 relays: 240 V $\sim$ - 6 A Enables to remotely control different  | f modules<br>1             |
| 1           | 4 149 25    | Consumption: 0.418 W - 34.8 mA (12 V =)<br>3-phase measuring module +<br>3 coils up to 3200 A  | 1                            |      |                       | electrical loads or motorised controls<br>associated to <u>rail</u> mounting protection<br>devices or head equipment (DPX <sup>3</sup> MCCBs)   |                            |
| 1           | 4 149 27    | Consumption: 0.418 W - 34.8 mA (12 V =)<br>3-phase measuring module +<br>3 coils up to 6300 A<br>Consumption: 0.418 W - 34.8 mA (12 V =)<br><b>Connection with CT</b>  | 1                            |      |                       | Equipped with DIP switches (on the side)<br>allowing product configuration: contact<br>type (NO + NC, 2 NO, etc) and function<br>(maintained or momentary contact)<br>Consumption: $0.456$ W - $38$ mA ( $12$ V $\pm$ )   |                            |
| 1           | 4 149 23    | 5 A measuring module connected via   | 1                            |      |                       | Control and state reporting module  |                            |
|             |             | current transformers (CT)<br>Consumption: 0.391 W - 32.6 mA (12 V = )  |                              |      |                       |   | Number                     |
| 1<br>1      |             | Extension kits for Rogowski coils<br>Supplied with connectors<br>Length: 1 m<br>Length: 3 m  |                              | 1    | 4 149 31 <sup>1</sup> |   | f modules<br>1             |

1: Enables upstream busbar connection

#### CX<sup>3</sup> energy management system (continued)



Conform to IIEC/EN 61131-2 (Programmable controllers) CX<sup>3</sup> energy management system enables to measure, control and visualize the state of <u>r</u> rail mounting protection devices (MCBs, RCCBs, RCBOs, etc...) or head equipment (ACBs, MCCBs, etc...), locally ("Stand alone") or remotely. All the modules of the system are equipped with two specific communication ports: one at the backside (for communication rail) and one underneath (for patch cords). Power supply with specific module Cat.No 4 149 45 Remote configuration possible with the help of the Energy Management Configuration Software, available for free download via E-Catalogue (giving also access to a 30-day trial version of Energy Management Software Cat.No 4 149 38/39)

| Pack | Cat.Nos               | Stand alone configuration module  |   | Pack        | Cat.Nos  | Communication interfaces   |                           |
|------|-----------------------|---|---|-------------|--|--|---------------------------|
|      |                       | ு <b>rail mounting</b><br>Optional module for "stand alone"<br>supervision need   | Number<br>of modules  | 1           | 4 149 40                                       | <b>RS485 / CX<sup>3</sup> energy management system</b><br>RS485 / CX <sup>3</sup> energy management system<br>conversion   | Number<br>of modules<br>1 |
|      |                       | Enables to configure, test and control CX <sup>3</sup> energy management system and to visualize supervision data No computer or IP connection required   |   | 1           | 0 046 89                                       | Consumption: 0.344 W - 28.7 mA (12 V = )<br><b>RS485 / Ethernet</b><br>RS485 / Ethernet conversion (for<br>connection to an IP network)  | 3                         |
| 1    | 4 149 36 <sup>1</sup> | Consumption: 0.438 W - 36.5 mA (12 V =)<br>Menu languages: English, French,   | 4   |             |  | Power supply module  | Number<br>of modules      |
| 1    | 4 149 37 <sup>1</sup> | Italian, Flemish, Polish, Spanish, German,<br>Portuguese and Turkish<br>Menu languages; English, Arabic,<br>Chinese, Greek, and Russian   | 4   | 1           | 4 149 45                                       | 500 mA 12 V $=$ stablized power supply module for CX <sup>3</sup> energy management system   | 1                         |
|      |                       | Energy management software for  | ļ   |             |  | Connection accessories<br>Communication rails  |                           |
| 1    |                       | <b>1 computer (user licence key)</b><br>Allows remote configuration, test, control a<br>visualization of data collected from EMDX<br>energy meters and multi-function measuri<br>and CX <sup>3</sup> energy management system on co-<br>computer connected to the network<br>30-day free trial version available for down<br>E-Catalogue<br>Software licence agreement (user key) for<br>Modbus adresses or 32 pulse modules<br>Software licence agreement (user key) 25<br>adresses or 255 pulse modules | <sup>3</sup> electrical<br>ng units<br>one<br>nload via<br>- 32 | 1<br>1<br>1 | 4 149 02 <sup>2</sup><br>4 149 03 <sup>2</sup> | To be fitted on <u>r</u> rail or spacer<br>Allows data transmission between the different<br>modules of CX <sup>3</sup> energy supervision system<br>18 modules<br>24 modules<br>36 modules<br><b>Communication patch cords</b><br>Allows data transmission between the different<br>modules of CX <sup>3</sup> energy supervision system<br>Can be used instead of communication rails<br>to create a link between two rows (individual | ent                       |
|      |                       | Energy management multi-support   | t web   | 1           |  | connected with communication rails)<br>Length 250 mm (10 patch cords)  |                           |
|      |                       | servers<br>Allow remote configuration, test, control a<br>visualization, via a web browser on PCs,  | nd  | 1<br>1      |  | Length 500 mm (10 patch cords)<br>Length 1000 mm (5 patch cords)<br>Communication patch cord connector   |                           |
|      |                       | smartphones, web viewers, tablet comput<br>data collected from: protection devices (E<br>modules with integrated measurement coi<br>DPX <sup>3</sup> and DMX <sup>3</sup> ). EMDX <sup>3</sup> electricity meters   | DX <sup>3</sup> add-on<br>ntrol unit,<br>s and                  | 1           | 4 149 10                                       | Enables to extend communication patch cor<br>length by clipping them together<br>Max. length: 3 m<br>Plastic cover for communication rail  | ds                        |
|      |                       | multi-function measuring units, CX <sup>3</sup> energy<br>management system and Green'up charg<br>for electric vehicles.  |   | 1           | 4 149 14                                       | Must be used for protection of the unused pathe communication rail   | arts of                   |
|      |                       | ு <b>rail mounting</b><br>Direct IP connection  | Number<br>of modules  |             |  | Length: 36 modules<br>Can be cut to the required length.   |                           |
|      |                       | Power supply: 9 to $28 V =$ with the<br>help of a single-phase switching mode<br>power supply Cat.No 1 467 21 to be<br>ordered separately   |   |             |  | Fixing: direct clip on to the rail<br>1: Enables upstream busbar connection<br>2: For other lengths, please consult us   |                           |
| 1    | 4 149 47              | For 10 Modbus adresses or 10 pulse<br>modules   | 4   |             |  |  |                           |
| 1    | 4 149 48              | For 32 Modbus adresses or 32 pulse modules  | 4   |             |  |  |                           |
| 1    | 4 149 49              | Fixing on plate<br>For 255 Modbus adresses or 255 pulse m<br>Supplied with external power supply and t<br>brackets  |   |             |  |  |                           |

| Notes |  |
|-------|--|
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |

| Notes |  |
|-------|--|
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |
|       |  |

#### FOLLOW US ON

| @   | www.legrand.com            |
|-----|----------------------------|
| You | www.youtube.com/user/legra |
| y   | twitter.com/legrand_news   |
| P   | pinterest.com.legrandgroup |
|     |                            |

#### **C**legrand

**World Headquarters** and International Department 87045 Limoges Cedex - France ☎: + 33 (0) 5 55 06 87 87 Fax: + 33 (0) 5 55 06 74 55